

Smart Watch

The smart watch is designed for the elderly and lone worker. The watch combines many intelligent functions, such as SOS alarm, two way talking, heart rate, pedometer and so on. The operation is very simple. Please read this operation guide carefully before using it.

1Getting To Know Your Watch

Front

Touch Screen

Power Button

SOS Button

Watch Strap

Back

Heart Rate Sensor

Charging Contacts

Microphone

Side

SIM Card Holder

Speaker

2Accessories

USB Cable

Watch Strap

Charging Base

User Manual

3SIM Card Installation

Please do as below picture shows.

1Remove Strap from watch.

2Remove SIM card holder from the watch and put a Nano SIM on the holder.

3Put the holder back and lock the strap on watch.

4Charging your Watch

Charging Pins

Charging Contacts

Charging

Connect the USB cable from charging base to the AC adaptor.

Place the watch into the charging base correctly, you will hear spoken confirmation "your watch is charging".

Please fully charge the battery daily for around 2 hours or when battery is low.

TIP

The watch battery is not removable. After a long period of inactivity, the watch may not be turned on due to low battery. please charge it every day to ensure that the watch can work normally.

5Functions and Basic Settings

When the watch is turned on, slide leftwards or rightwards to view all available functions. It displays Watch Face, Weather, Heart Rate, Contact, Steps and Settings.

1At watch face, you can see time, date, heart rate and steps.

2There are two watch faces for your option. Sliding right to the end and click settings, select watch face and choose what you like by sliding left and right.

6Making a phone call

Contact

Slide rightwards to enter the interface of Contact, select the contact person, and make a call.

7Steps

Step counter

Keep sliding right to enter the interface of Steps, step counting is enabled by default and opened all day. You can also view distance and consumed calories.

www.eviewgps.com

8Heart Rate Measurement

Heart rate

Wear the watch on the left hand and click heart rate, after several seconds checking, the screen the will display your heart rate BPM.

9Activating an SOS Alarm

There are two ways to activate SOS alarm.

1Pressing the side button for 3 seconds until you feel the watch vibrate.

2When screen is on, long press the screen for 3 seconds until you feel the watch vibrate.

After SOS alarm is activated, you will hear a voice prompt confirming the activation of the SOS alert and allowing you approximately 10 seconds to cancel the alarm. If the SOS is not cancelled in time an SOS alert text message is immediately sent to the emergency contact numbers followed by the outgoing calls.

If the watch fails to connect to the first number, it will call the second number after delay of 10 seconds. In case the second number fails to be connected as well, the system will connect to the third number etc.

Between each call, it will have 10 seconds delay, during this time, user can stop call sequence or prevent a possible false alarm by pressing SOS button.

10Notes on Voicemail

We advise emergency contacts to switch off any voice mail facility on their phone to prevent delay in reaching help. However, the followin safe-guards are used if a voicemail is reached:

The wearer can end the current call by clicking the SOS button and the calling sequence to continue if the voice mail does not automatically disconnect.

An emergency contact can call back to the watch if they are disconnected. Remember that the watch maybe already calling the next contact unless the calling sequence has been stopped.

11Fall Alarm

The watch can automatically detect a fall. When this occurs the watch will give a warning message to the user.

some daily activities like sports oe even sitting down abruptly can trigger the fall alarm.

The wearer has a short time to cancel a fall alarm by clicking the Cancel on the watch. If the alarm is not cancelled, emergency contacts will be called.

TIP

It is possible that the watch will not detect every real fall. We **strongly** advise the wearer to press the SOS button in any emergency situation, if they are able.

12Getting a GPS fix

To get an initial GPS fix, go outdoors or near a window so the watch can get a fix on the satellites. This could take few minutes depending on your environment.

TIP

GPS functionality may be unavailable or inaccurate in some locations (for example, availability or accuracy of GPS location maybe impacted inside buildings or near tall buildings or other tall features or underground).

The watch also provides Wi-Fi, LBS positioning, when GPS is unavailable, it will switch to Wi-Fi and LBS for locating.

The home Wi-Fi and beacons provide at home out of home information in addition to optimizing watch battery life.

Please note Wi-Fi and LBS tracking service is not 100% accurate, it can be used to approximate your location only.

13General Specifications

Dimension: 47.5mm*16.9mm/1.87in*0.66in.

Weight: 65g/2.29oz.

Battery: Rechargeable, 3.7V,580mAh.

Charging voltage: 5V DC.

Waterproof: IP67.

4 locating technologies: GPS, BLE, Wi-Fi, LBS.

TIP

Please comply with the instructions to extend the watch life:

Don't use & store the watch in dusty, hot, cold, electric, chemical, areas. Please always keep the watch and accessories dry.

Don't drop, shake or knock the watch, Rough handling can break it.

Clear the watch with a piece of dry cloth. Don't clean in chemicals, detergent.

Don't disassemble or refit the watch as it will void your warranty.

Using other batteries will cause unwanted situation.

To avoid accident, never play the watch while driving.

Please turn off the watch in aircraft and follow any restrictions. Wireless devices can cause interference in aircraft.

Smart Watch

SOS